

How To Install Artificial Boxwood Hedge

Installation:

First: Preparing Tools For Installation

Tools: Cable Ties, Scissors (Grid, Air Pump, Gun Nails If Installed on wall)



Second: Specific Steps

1. According to the actual area, artificial boxwood hedge should be stitched together in same direction. Note: the direction of stub around four side.



2. After putting together the artificial hedge, rolled them up to a size for your convenience.



3. From one side to begin when installation. One person use the cable ties to fixed artificial hedge on the Garden Fence, Another person help to accomplish this step. Please fixed the items top then all-around.



4. Sort out the artificial boxwood hedge, and cut the exposed parts. Now, the installation is finished. It is easy and convenient.

Contact:Mr.Frank

Email:frank@dyartificial.com

TEL:+86 15575464987